



USER INSTRUCTIONS

Mexican Chimeneas



**WARNING - Observe these instructions to avoid personal injury and damage to property
NEVER leave a burning fire unattended
HOT Burn risk**



Gardeco Limited
PO Box 5500, Kidderminster, Worcestershire, DY11 9BB
Tel: 0870 234 0003 Fax 0870 234 0017
E-mail: info@gardeco.co.uk www.gardeco.co.uk



USER INSTRUCTIONS OUTDOORS

Please read the following instructions and recommendations and use CAUTION at all times for the safe enjoyment of a Mexican chimenea. Please keep these instructions in a safe place so you can read them again from time to time.

- **ALWAYS FOLLOW THE USER INSTRUCTIONS.** Failure to do so may result in personal accidents or fires spreading to property. Please remember, you are dealing with a real fire.
- PLACE your chimenea on a FLAT surface; you should NOT place it on a sloping surface where the fire might tip over.
- This should be a NON-FLAMMABLE surface such as stone, gravel or bricks. Do not place on grass which may turn brown. Do not place on wood which may turn brown or catch fire. DO NOT PLACE ON DECKING which may turn brown or catch fire.
Protect wooden decking with a Gardeco FLOOR PROTECTOR or use bricks or concrete slabs.
- DO NOT place your chimenea near bushes or plants or under trees; the heat will damage the leaves and is a fire risk.
- DO NOT place your chimenea under an awning; it will burn or melt.
- DO NOT place your chimenea near garden furniture, especially made of fabric or woven plastic, which may melt or catch fire. We recommend at least one metre minimum distance.
- DO NOT make a real fire inside a conservatory or summer house or shed; real fires are designed to be outside, and fumes emanating from the fire made with wood, coal or charcoal are toxic and dangerous to health. You can use your chimenea indoors ONLY WHEN USING WITH THE GARDECO CHIM BURNER AND BIO-ETHANOL FUEL.
- DO NOT touch the chimenea when burning; the surface is hot and you will burn your fingers; protect your hands with a Gardeco FIRE GLOVE. We recommend that gloves are used at all times.
- DO NOT allow children, especially small children, near the fire. Do not allow pets near the fire.
- DO NOT allow children to play or run around the fire. Use a Gardeco CHIMENEA GUARD to prevent small children coming close to the fire.
- DO NOT over fuel the chimenea. If flames are coming out of the top of the chimenea, then the fire is too large.
- DO NOT PANIC if fuel falls out of the chimenea or for any reason flames spread out from the fire, simply extinguish spreading flames with earth or sand or water or use a Gardeco FIRE BLANKET immediately.
DO NOT throw water on a real fire other than in an extreme emergency.
- DO NOT use petrol, paraffin or similar substances as fire lighters or as a fuel. The best method is balled newspaper and kindling, such as Gardeco OCOTE sticks. The best fuel is wood or charcoal.
REMOVE the charcoal grill when not burning charcoal.
- **NEVER LEAVE A BURNING CHIMENEA UNATTENDED.** Failure to do so may result in the fire spreading out of control and damage or destruction of property. Please ensure the fire is completely out before leaving the chimenea unattended.
- We advise against using a real patio fire when it is windy or in the case of strong drafts. Strong wind may tip the chimenea over which is a fire risk. Wind may also disperse burning material, which is a fire risk, particularly if the environment is very dry.
- Please be a good neighbour and be reasonable in the use of your patio fire, keep smoke and noise to a minimum.



SPECIFIC INSTRUCTIONS FOR YOUR CHIMENEA

- This is a clay chimenea of genuine Mexican design, handmade by craftsmen. Use your clay chimenea for warmth and outdoor cooking. It is beautiful to look at and can be used as a garden decoration.
- Before lighting, put 50mm (2 inches) of Gardeco LAVA STONES or sand/gravel in the bottom to protect the base from direct heat. Failure to do this may crack your clay chimenea
- Start the fire with balled newspaper, dry kindling or gardeco OCATE sticks. NEVER use petrol or spirit based lighting fuels. They may crack your chimenea.
- You may use dry wood logs or charcoal fuel. Clay chimeneas and other patio fires can be used to burn garden refuse such as leaves or branches. DO NOT throw fuel into a clay chimenea.
- Wet logs will create a lot of smoke. Use seasoned or kiln dried wood to minimise smoke.
- It is essential to allow the clay chimenea to warm up slowly by keeping the fire small for the first 20 minutes. Add more firewood later but do not build a large roaring fire which may crack the chimenea and is dangerous. Never feed fuel through the funnel.
- The environmental friendly fuel is wood or charcoal which is carbon neutral.
- When cooking use locally made charcoal from renewable forests with minimal transport cost. Gardeco Wyre Forest Charcoal is made in the Wyre Forest in the UK West Midlands following ancient rural methods.
- Gardeco CHIMLOGS, which are made from recycled sawdust and burn slowly with little smoke.
- For a fire without firelighters or kindling, use the smokeless Gardeco FIRELOG, a wax impregnated sawdust briquette, wrapped in a paper. Just light both ends of the paper and the log will burn for about 2½ hours. You cannot use Gardeco Fire Logs for cooking.
- Protect hands with Gardeco FIRE GLOVES when adding fuel. The more fuel is added, the more intense the heat, the larger the flames. Do not over-fuel the fire.
- Use a Gardeco POKER to reposition logs inside the patio fire.
- If the fire is slow to start, more air will help, use a Gardeco BELLOWS to blow air into a slow fire.
- Safety is our main concern, so please use a CHIMENEA GUARD to keep small fingers away from the fire.

MAINTENANCE INSTRUCTIONS FOR YOUR CLAY CHIMENEA

- Clay chimeneas are not frost-proof. The chimenea has no drainage, and clay is porous, absorbing moisture. Should your clay chimenea be left outside, saturated with water when it freezes, it may crack. This is a natural phenomenon which we cannot prevent. To stop this process, keep your clay chimenea dry. Bring it inside or cover it. Make sure your chimenea is dry before covering it up or you will be sealing the moisture under the cover. Gardeco offer no guarantees on clay chimeneas against frost damage.
- Mexican chimeneas do not like to be left in a damp environment for too long. It weakens their structure. If your chimenea has been allowed to become sodden with rainwater for a while, or has been kept unprotected in a cold and wet environment, you need to be careful if attempting to move it. Better wait for it to dry. Clay chimeneas are fragile. They will crack or shatter if dropped or knocked.
- With use, the paint finish on your chimenea will change and discolour, and there will be blackening around the rim. The bigger the fires, the faster the paint finish will change.
- A clay chimenea can be re-painted with ordinary household emulsion paint after rubbing down to remove any loose paint. The shiny glaze effect paint finish will peel and burn when heated to a high temperature and will peel off if left outside in the winter. Gardeco offer no guarantees on the paint finish.
- The stand is made of steel and will rust. To reduce the likelihood of rusting bring the chimenea and stand inside or protect with a Gardeco weatherproof cover. Ideally, bring inside for the winter. Stands can be repainted.
- Rust runs may mark flooring, slabs, and patios, so if you are worried about marking, protect your flooring.
- A discoloured chimenea on a rusty stand is still fit for purpose and can continue to be used.
- Cracks in the clay may be repaired with Gardeco Chim Filler and continue to be used. If a large structural crack appears, stop using the chimenea and dispose of it. All clay chimeneas crack eventually.



USING THE BIO-ETHANOL CHIM BURNER INDOORS

Bio-ethanol burns without smoke, soot or ash. Simply position your chimenea in a safe place in your house, and it turns into a real flame decorative heater! NEVER move your chimenea while the fuel is burning or when there is fuel left inside the Chim Burner.

Please read, retain and follow the instructions and recommendations and use caution at all times for the safe enjoyment of your chimenea and bio-ethanol Chim Burner.

DO NOT put on carpets, wooden or plastic flooring which may mark or catch fire.

DO NOT place your chimenea near curtains, soft furnishings which may melt or catch fire. We recommend a minimum distance of 1 metre from any such materials.

DO NOT place your chimenea near plants or items sensitive to heat. They will be affected by the heat and it is a fire risk.

DO NOT place your chimenea where it is likely to be knocked over or bumped into.

DO NOT place your chimenea under or near electrical cables or installations. It is dangerous.

DO NOT place your chimenea underneath lamps or other fittings. It is dangerous and a fire risk.

DO NOT lean over the fire and flames. Hair burns at low temperature and very quickly.

DO NOT bring your face near the flames.

DO NOT cover or leave clothes or newspapers on or near the chimenea. They are a fire risk.

DO NOT use the chimenea to dry clothes which may catch fire.

DO NOT allow children, especially small children near the chimenea. Especially DO NOT allow children to play or run around the fire. It is NOT a toy. KEEP pets away from the chimenea.

OBSERVE the minimum room size requirements of 22 cubic metres. DO NOT place the chimenea in an unventilated room.

DO NOT leave a fire unattended at any time. We recommend placing a fire extinguisher near to your fire as a safety precaution.

BIO-ETHANOL CHIM BURNERS

Gardeco
BIO-ETHANOL
CHIM BURNERS

BRING YOUR
CHIMENEA INSIDE
THE HOUSE

Now you can enjoy an instant fire with no logs, no smoke and no mess in any chimenea or fire bowl and you can bring your chimenea or fire bowl into the house and use as a decorative additional heater.

Bio-ethanol is environmentally-friendly and burns without smoke, leaves no soot or ashes, lights instantly and snuffs out in seconds.

Universal Chim Burner



Small Chim Burner



Gardeco
BIO-ETHANOL
CHIM BURNERS

INSTANT FIRE
NO LOGS,
NO SMOKE,
NO MESS



COOKING ON A CHIMENEA OR FIRE BOWL OR BBQ

Special care and attention is necessary when cooking on a chimenea or fire bowl to avoid contamination by smoke or soot.

All cooking accessories **MUST BE THOROUGHLY CLEANED BEFORE USE.**

- BBQ grills and other accessories are coated with vegetable cooking oil during manufacture but may have gathered dirt and dust therefore need to be cleaned in hot water and detergent to remove any foreign matter and debris.
- After cleaning and drying, cooking accessories are best lightly coated with vegetable cooking oil before use. After use, they need to be cleaned again with hot water and detergent and coated with vegetable cooking oil before storing. **NEVER USE MINERAL OIL.**
- If you do not oil cooking accessories they will rust, this could happen after first use. If you wash cooking accessories with water and don't coat with cooking oil rust can occur in a matter of hours.
- After use the surfaces of the cooking accessories in direct contact with the fire will be covered in black carbon soot. Soot can be washed off with hot water and household detergent or washing up liquid. Be careful because black soot residues will mark surfaces, tea towels or washing up cloths. All soot must be removed before oiling and storage.

FUEL

Do not cook on flames, if you do this there will be a soot residue on the food, which is unhealthy. Be aware wood is often treated with preservatives which are toxic and can contaminate the food.

- When cooking use dry wood or charcoal, and allow the wood gas to burn off as flames to leave hot glowing embers, cook on the embers.
- If meat releases fat onto the hot embers which makes a flame, move the meat away from the flame.
- Keep a spray bottle of water handy to squirt on any flames.
- Used a cast iron pan to grill meat rather than placing directly on a grill.
- Alternatively wrap food in aluminium foil to prevent contamination.

FOOD HYGIENE AND SAFETY

When cooking outdoors take care food is kept in hygienic conditions.

- **DO NOT** leave meats in the sun or outside in hot weather, keep cool and covered with a clean cloth.
- **DO NOT** leave butter in the sun or uncovered.
- Keep meat and vegetables in separate dishes to avoid cross contamination with fluids.
- Only bring food out into the garden before cooking and it should be consumed after cooking as soon as possible. Food should be eaten while hot, immediately after coming out of the fire. Dispose of any cooked food not eaten.
- **MAKE SURE** meat is thoroughly cooked.
- When cooking accessories are taken out of the fire, they are hot and need to be put onto a hard non-flammable surface, so the contents of the cooking accessory can be removed.
- **DO NOT** place the cooking accessory on the patio, grass, earth or directly on the ground. Best use a Gardeco chim table or Gardeco cradle for clay chimeneas.
- **DO NOT** put hot cooking accessories directly onto wood, furniture, plates, crockery or plastic surface.
- Parts of the cooking accessories in direct contact with the fire may become covered with carbon soot. Make sure you do not contaminate your food with soot.
- **CAREFUL HOT! DO NOT TOUCH**, steel and cast iron cooking accessories are very hot when taken out of the fire, do not touch with your fingers, protect hands with Gardeco **FIRE GLOVES**.
- Cast iron cooking accessories can remain hot after use, so **ALWAYS** be very careful and cautious when handling cast iron cooking accessories.
- **DO NOT** allow children to handle any of the cooking accessories.
- **NEVER** leave a cooking accessory in the fire unattended. If you leave food in the fire, it will be burnt and inedible.



HINTS AND TIPS

- Cast iron accessories should be pre-heated for best results.
- Always coat the inside with oil or butter of all accessories to prevent food sticking.
- Butter tastes better than oil for waffles and pancakes.
- A small brush is useful for oiling or buttering surfaces.
- A flat spatula is useful to release foods from the accessory.

WHICH COOKING ACCESSORIES SHOULD I USE?

Gardeco cooking accessories are specially designed for use in chimeneas, fire bowls, barbecues or outdoor fires. The materials used are suitable for the greater intensity of outdoor fires, with long handles to ensure ease of use without burning your hands. It is **NOT ADVISABLE TO USE KITCHEN PANS OR POTS** to cook on patio fires. Kitchen pans may be designed for fires of less intensity and coated with plastic based non-stick materials which may melt in patio fires. Gardeco cooking accessories are designed for cooking food on an open fire.

- The Gardeco **COOKING IRON** is perfect for burgers, sausages, vegetables; it is multi-purpose.
- The Gardeco **TOASTIE IRON** makes tasty sandwich toasties.
- The Gardeco **FRYING PAN** is great for steaks, bacon, frying tomatoes and fried eggs.
- The Gardeco **POP CORN POPPER** is great for entertaining children, who love watching popping corn.
- The Gardeco **PANCAKE PAN** for making pancakes.
- The Gardeco **WAFFLE IRON** for making waffles.
- The Gardeco **CHESTNUT PAN** for roasting tasty chestnuts and can be used for cooking food wrapped in aluminium foil.
- The Gardeco **TOASTING FORK** makes delicious toast and marshmallows, or to warm rolls or croissants.
- The Gardeco **PIZZA STONE** is great for making pizzas the Italian way.
- Use the Gardeco removable **CHIM BBQ GRILL** on clay chimeneas, for cooking food on BBQ grill
- Your cast iron or steel chimenea may already be equipped with a **SWIVELLING BBQ GRILL**, made of either chromed steel or cast iron for barbecuing on your chimenea. These can also now be purchased separately from the chimenea itself.
- The Gardeco **SWIVELLING HOT PLATES AND FRYING PANS** can be fitted in place of the BBQ grill on most steel

MORE RECOMMENDATIONS

All cooking accessories, whether supplied with the product or separately must be washed before first use to remove any potential dirt due to manufacture or packaging operations. We recommend you also wash them before use every time subsequently, even if they were put away clean.

All cast iron cooking accessories including BBQ grills and hot plates are coated with vegetable oil to stop rusting when you first get them. After use, all cooking accessories need to be cleaned in soapy water to remove soot and cooking residue. Dry them well after cleaning and immediately coat them with vegetable oil before putting away. Failure to coat with vegetable oil will mean the accessory will start rusting. **NEVER** use mineral oil which is harmful to human health. For cooking accessories purchased separately from this product, follow the cooking instructions supplied with the packaging.

If your chimenea is equipped with a swivelling cast iron BBQ grill, remember to remove and wash it thoroughly and coat it with vegetable oil before and after use. Put food directly onto the BBQ grill, either pre-heated or not. For pizzas, use the pizza stone. Use the multi-purpose tool provided to swivel the BBQ grill in and out. **Never** touch the BBQ grill with your hands while hot. A cast iron BBQ grill will remain hot a long time after use, even if taken out of the chimenea.



ACCESSORIES AVAILABLE FROM GARDECO

FOR COOKING

<p>Cooking Irons</p>	<p>Toastie Iron</p>	<p>Frying Pans</p>
<p>Pop Corn Popper</p>	<p>Pancake Pan</p>	<p>Waffle Iron</p>
<p>Chestnut Pan</p>	<p>Toasting Fork</p>	<p>Medium BBQ Grill</p>
<p>Large BBQ Grill</p>	<p>Chromed Steel BBQ Grill</p>	<p>Medium Hot Plate</p>
<p>Large Hot Plate</p>	<p>Pizza Stone 30 cm</p>	<p>Pizza Peel</p>
<p>Raking Tool</p>	<p>Removable BBQ Grill</p>	<p>Multi-Purpose Tool</p>



COVERS

Chimenea shaped covers made of UV treated woven polyethylene



Fire pit covers made of UV treated woven polyethylene




PVC covers



Special shaped covers made of UV treated woven polyethylene



Padded Winter Coats



Special Covers



FIRE SAFETY PRODUCTS

Floor protection



Chimenea Guard




Fire Gloves



Carbon Monoxide Detector



Fire Blanket



Fire Blanket





LOOKING AFTER YOUR CHIMENEA

Lava Stones



Heat-resistant paint in black & bronze



Chim Protect



Chim Cleaner



Chim Filler



FOR ENHANCING THE USE OF YOUR CHIMENEA

Ceramic Logs



Poker & Companion Set



Bellow

Extension



Flame Lamps



Log Holder



FUELS

Ocote sticks bundle



Ocote bag 1kg



Firelog



Fire gel



Chim Logs



Wyre Forest Charcoal

