#66640 Ganger

| Parts List | Hardware List |
|------------|---------------|
| | |

| Part | Drawing | Description | Qty | Part | Drawing | Description | Qty |
|------|----------|---------------|------|------|-------------|-----------------------|------|
| P-1 | Q MARKET | Ganger-Rubber | 2 EA | А | Ball-Head | Wood Screw | 4 EA |
| | , C | | | В | Ball-Head | Machine Screw- 6mm | 4 EA |
| | | | | С | Ball-Head N | Machine Screw-1/4"-20 | 4 EA |

For Tables with Predrilled Tops:

- 1. Pick the side of the Tables you want to gang.
- 2. Screw in two Ball-Head Wood Screws (A) into the predrilled holes in the bottom of your Tables. See illustration #1.
- Snap and Stretch the Ganger in place over the Ball-Head Screws.

For Tables with Treaded Inserts:

- 1. Pick the side of the Tables you want to gang.
- 2. Determine thread size of your threaded inserts.
- 3. Screw in two Ball-Head Machine Screws (B or C) into the embedded treaded inserts in the bottom of your Tables. See illustration #2.
- 4. Snap and Stretch the Ganger in place over the Ball-Head Screws.

