








ASSEMBLY INSTRUCTIONS

PARTS LIST


A x1 	B x4 	C x8 
D x8 	E x8 	F x1 

ASSEMBLY


STEP 1 Put the Bench Seat (A) upside-down and detach the cover from the Velcro on the frame, and remove the package with the legs and the screws.




STEP 2 Assemble the corner legs (B) to the seat frame (A) using washers (C), O'Rings (D) and bolts (E), as shown.



STEP 3 Re-attach the seat cover to the Velcro on the frame as shown.




If the legs feel uneven, unscrew loose all the bolts just a little bit, seat on the bench and then re-tighten the bolts.



SEE REVERSE FOR CARE, MAINTENANCE AND WARNINGS

CARE, MAINTENANCE
AND WARNINGS:

THE WEIGH LIMIT ON THIS PRODUCT IS 330 Lbs. (150 Kgs)



- Do not exceed the indicated weight limits.
- Do not stand up on the bench or use it as ladder.
- Do not allow small children to play under the bench or jump on the seat cushion.
- Do not leave small children on the bench unattended.
- Do not expose the surfaces to direct sunlight or to extreme environmental conditions.
- Clean the surfaces preferable with a clean cloth damped in a solution of mild soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean the unit.
- If you decide to use a cleaning agent, test first on an area hidden from view such as underneath the seat.
- Every 4 month, inspect the legs to make sure the wood is not cracked/split, and also make sure that all the screws are properly tightened.
- When transporting the unit to places far away, protect and secure the unit to avoid damage in transit.
- Shall any part of the unit become defective during the warranty period, replacement parts might be available to you at no charge. Please refer to the WARRANTY card included with the product.
- The warranty does not extend to regular wear and tear, nor the manufacturer assumes liability for damages or consequences due to accidents, incorrect assembly, negligence, improper use, modifications, or not heeding the above warnings.

SEE REVERSE FOR PARTS LIST AND ASSEMBLY