

ASSEMBLY INSTRUCTIONS FOR YOUR DOUGHNUT WALL SCONCE

IMPORTANT SAFETY INSTRUCTIONS:

- *These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- *WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN
- *Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- *DO NOT subject the fixture to any shock while lit as shattering of bulbs may result.
- *Do not connect the electricity until lamp is fully assembled.

CORD COVER ASSEMBLY INSTRUCTIONS:

1. Remove the mounting plate (A) from the backplate of the light fixture (B) by removing screws (E).
2. Affix the mounting plate (A) to the wall with the mounting plate screws (C) and anchors (L) provided.
3. Hold backplate (B) over mounting plate (A). Thread screws (E) into vacant holes at the top and bottom of backplate (B) to secure fixture to mounting plate (A).
4. Thread cord cover (D) into nipple (M) at bottom of backplate.
5. Put harp (F) into harp saddle by squeezing both sides of the harp.
6. Remove the finial (H) from the shade harp (F) and attach the lamp shade (G). Secure lamp shade (G) to the shade harp by tightening the finial (H).
7. Install one (1) 100W MAX. Type A, medium base bulb into socket.
8. Insert three prong plug (K) into wall outlet.

DIRECT WIRE ASSEMBLY INSTRUCTIONS

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Remove the mounting plate (A) from the backplate of the light fixture (B) by removing screws (E).
3. Cut the three prong plug (K) from the end of electric cord and remove the cord cover (D) if attached.
4. From the back side of the lamp, pull the electric cord up through the nipple (M) at the bottom of the backplate (B).
5. Using a wrench remove nipple (M) from backplate (B). Insert plug (J) into the hole vacated by the nipple and thread sleeve (I) on to screw plug (J) inside the backplate (B).
6. Cut the cord to the desired length for making connection to outlet box.
7. Gently pull the wiring from the wall outlet box and thread the wires through the center hole in the mounting plate (A).
8. Affix the mounting plate (A) to the wall outlet box with the mounting plate screws (C) provided.
9. Connect the ground wire (green) from fixture to ground wire in the outlet box.
10. Connect the white wire of the fixture to the neutral wire in the outlet box. Fasten wires together with wire nut (N) and tightly wrap connection with electrical tape.
11. Connect the black wire of the fixture to the hot wire in the outlet box. Fasten wires together with wire nut (N) and tightly wrap connection with electrical tape.
12. Attach fixture (B) to the mounting plate (A). Tighten fixture (B) by the base screws (E).
13. Follow steps 5 - 7 in *cord cover assembly instructions* above for completion of assembly.

