

We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-888-996-2729 FAX: 1-866-873-3531 gameroom@escaladesports.com

Or write to:
Escalade Sports
Customer Service Department
P.O. Box 889
Evansville,IN 47706

Please visit our Web site at:

www.escaladesports.com

Please have your date code when inquiring about parts.


When contacting Escalade Sports please provide your model number, date code (if applicable), and part number if requesting a replacement part. These numbers are located on the product, packaging, and in this owners manual.

Your Model N	Number	F	T200
Date Code:_	2 - F	Т200 -	- MW
Purchase Da	ate:		

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

1

IMPORTANT! READ EACH STEP IN THIS MANUAL BEFORE YOU BEGIN THE ASSEMBLY.



# TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS FT200 SOCCER TABLE

## **Tools Required:**

A2 & A3 - Allen Wrench (Included)
Phillips Screwdriver
Furniture Polish and Cloth

An electric screwdriver is helpful in assembly. However, please set at low torque and use extreme caution with an electric screwdriver because you could overtighten the hardware and strip the screws.

# **Assembly Tips**

Make sure you understand the following tips before you begin to assemble your soccer table.

- 1. Start all bolts by hand before tightening.
- 2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.



READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO ADULTS ARE NEEDED TO PUT THIS SOCCER TABLE TOGETHER.

P1 = 2 pcs	P2 = 2 pcs	P3 = 1 pc	P4A = 2 pcs
Side Apron	End Apron	Playfield	Left Leg
RPFT20-P1	RPFT20-P2	RPFT20-P3	RPFT20-P4A
P4B = 2 pcs	P5 = 2 pcs	P6 = 8 pcs	P7 = 3 pcs
Right Leg	Leg Cross Tube	Rod Handle	Playfield Support Brace
	NOTE: Parts are packed inside of Leg.		NOTE: Parts are packed inside of Leg.
RPFT20-P4B	RPFT20-P5	RPFT20-P6	RPFT20-P7
P9 = 2 pcs	P10 = 8 pcs	P11 = 2 sets	
Wooden Ball Catcher	Rod End Cap	Scorer	
		0 12345078910 0	
RPFT20-P9	RPFT20-P10	RPFT20-P11	
C1 = 2 pcs	C2 = 4 pcs	C3 = 2 pcs	C4 = 16 pcs
5 Player Rod	3 Player Rod	2 Player Rod	Rod Bumper
RPFT20-C1	RPFT20-C2	RPFT20-C3	RPFT20-C4
C5 = 32 pcs Rod Washer	C6 = 26 pcs 4mm x 25mm Phillips Round Head Bolt	C7 = 26 pcs 4mm Nut	C8 = 11 pcs Blue Shirt / White Short Player
		0	
RPFT20-C5	RPFT20-C6	RPFT20-C7	RPFT20-C8

NOTE: P5 AND P7 PARTS ARE PACKED INSIDE OF LEGS.



C9 = 11 pcs Red Shirt / White Short Player	C10 = 4 pcs One Player Rod Stop		
RPFT20-C9	RPFT20-C10		
H1 = 8 pcs 3.5mm x 25mm Phillips Round Head Screw	H3 = 3 pcs Playfield Support Rod	H4 = 6 pcs Allen Head Nut for Playfield Support Rod	H5 = 8 pcs 3.5mm x 25mm Phillips Round Head Screw
	NOTE: Parts are packed inside of Leg.		
RPFT20-H1	RPFT20-H3	RPFT20-H4	RPFT20-H5
H6 = 2	24 pcs	H7 = 24 pcs	H8 = 4 pcs
7.5mm x 50mm Allen Head Bolt		8.5mm x 19mm Flat Washer	3.5mm x 32mm Phillips Flat Head Screw
			\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
RPFT20-H6		RPFT20-H7	RPFT20-H8
A1 = 2 pcs Soccer Ball	A2 = 2 pcs 6mm Allen Wrench	A3 = 1 pc 4mm Allen Wrench	
RPFT20-A1	RPFT20-A2	RPFT20-A3	

**NOTE: H3** PARTS ARE PACKED INSIDE OF LEGS.



3 pcs - H3 Playfield Support Rod

6 pcs - **H4** Playfield Support Rod Nut

2 pcs - **P1** Side Apron 1 pc - **P3** Playfield


3 pcs - P7 Playfield Support Brace

2 pcs - A2 6mm Allen Wrench

#### STEP 1:

Find a clean, level place to begin the assembly of your soccer table. We recommend building the table on the box top to protect the parts during assembly.

With the help of another adult, carefully assemble **P1** Side Aprons, **P3** Playfield and **P7** Playfield Support Braces using **H3** Support Rods, **H4** Support Rod Nuts with **A2** Allen Wrenches as shown in **FIGURE 1**. **Do not tighten H4 Support Rod Nuts at this time.** 



8 pcs - H1 Phillips Round Head Screw 2 pcs - P2 End Apron

8 pcs - **H6** Allen Head Bolt 2 pcs - **A2** 6mm Allen Wrench 8 pcs - **H7** Flat Washer 1 pc - **A3** 4mm Allen Wrench

#### STEP 2:


Attach P2 End Aprons to previous assembly STEP 1 using H6 Allen Head Bolts with H7 Flat Washers as shown in FIGURE 2. Do not tighten H6 Allen Head Bolts on this time.

Please make sure **P3** Playfield is flush with both ends of **P2** End Apron, tighten **H6** Allen Head Bolts using **A3** Allen Wrench on this time.

Secure P3 Playfield to P2 End Apron using pre-drilled holes with H1 Screws as shown in FIGURE 2.

IMPORTANT NOTE: All screws must be screwed STRAIGHT down. Tighten, but do not strip out H1 Screws.

Using A2 Allen Wrenches to tighten H4 Support Rod Nuts as shown in FIGURE 2.




8 pcs - **H5** Phillips Flat Head Screw
16 pcs - **H6** Allen Head Bolt
2 pcs - **P4B** Right Leg
2 pcs - **P4B** Right Leg
2 pcs - **P5** Leg Cross Tube
2 pcs - **P9** Wooden Ball Catcher
1 pc - **A3** 4mm Allen Wrench

#### STEP 3:

Install **P9** Wooden Ball Catchers using **H5** Screws as shown in **FIGURE 3**. **Tighten, but do not strip out H5 Screws**.

Install **P4A** Left Legs and **P4B** Right Legs with **P5** Leg Cross Tubes using **H6** Allen Head Bolts with **H7** Flat Washers as shown in **FIGURE 3**. Use **A3** Allen Wrench to tighten all **H6** Bolts.



THIS STEP REQUIRES TWO OR MORE ADULTS.
VERY CAREFULLY TURN THE TABLE OVER AND
SET IT ON ITS LEGS.

1 pc - C1 5 Player Rod 16 pcs - C5 Rod Washer 11 pcs - C8 Blue Shirt / White Short Player 2 pcs - C2 3 Player Rod 13 pcs - C6 Phillips Round 2 pcs - C10 One Player Stop Rod 1 pc - C3 2 Player Rod Head Bolt 4 pcs - P6 Rod Handle 13 pcs - C7 Lock Nut 8 pcs - C4 Rod Bumper 4 pcs - P10 Rod End Cap

#### STEP 4:

Slide C1 5 Player Rod, C2 3 Player Rods and C3 2 Player Rod through Rod Bushings of one P1 Side Apron as shown in

FIGURE 4. IMPORTANT NOTE: Please note the location

of the hole that is near one end of each rod.

This is the handle end of the rod.

Place one C5 Rod Washer, C4 Rod Bumper and one C5 Rod Washer on each rod as shown in FIGURE 4.

Place C8 Blue Shirt / White Short Players ( ● ) and C10 One Player Stop Rod ( ) on rod as shown in FIGURE 4.

IMPORTANT NOTE: The goalie should be at your left and your team (player face) facing to the right. Looking ahead to FIGURE 8 - will help you with correct player and rod handle assembly onto rods.


Place one C5 Rod Washer, C4 Rod Bumper and one C5 Rod Washer on each rod as shown in FIGURE 4.

■ = **C8** Blue Shirt / White Short Player □ = C10 One Player Stop Rod

= C4 Rod Bumper

= C5 Rod Washer

**OVERHEAD VIEW LOOKING DOWN ONTO TABLE** 



#### STEP 5:

Align C8 Blue Shirt / White Short Player and C10 One Player Stop Rod to each player hole and attach using C6 Bolts with C7 Lock Nut as shown in FIGURE 5 and **DETAIL A**.

**Rod Bushing** 


already attached onto


each P1 Side Apron.

Attach P10 Rod End Caps to the rod as shown in FIGURE 5.

Slide P6 Rod Handle onto each rod end with the small hole shown in FIGURE 5.

IMPORTANT NOTE: A small amount of liquid soap applied inside each P6 Rod Handle will allow them to slip onto rod easier.





**OVERHEAD VIEW** 

1 pc - C1 5 Player Rod 16 pcs - C5 Rod Washer 11 pcs - C9 Red Shirt / White Short Player 2 pcs - C2 3 Player Rod 13 pcs - C6 Phillips Round 2 pcs - C10 One Player Stop Rod 4 pcs - P6 Rod Handle

8 pcs - C4 Rod Bumper 13 pcs - C7 Lock Nut 4 pcs - P6 Rod Handle 4 pcs - P10 Rod End Cap

#### STEP 6:

Slide **C1** 5 Player Rod, **C2** 3 Player Rods and **C3** 2 Player Rod through Rod Bushings of one **P1** Side Apron as shown in **FIGURE 6**.

IMPORTANT NOTE: Please note the location of the hole that is near one end of each rod. This is the handle end of the rod.

Place one **C5** Rod Washer, **C4** Rod Bumper and one **C5** Rod Washer on each rod as shown in **FIGURE 6**.

Place **C8** Red Shirt / White Short Players ( ○ ) and **C10** One Player Stop Rod ( ○ ) on rod as shown in **FIGURE 6**.

IMPORTANT NOTE: The goalie should be at your left and your team (player face) facing to the right. Looking ahead to FIGURE 8 - will help you with correct player and rod handle assembly onto rods.

Place one **C5** Rod Washer, **C4** Rod Bumper and one **C5** Rod Washer on each rod as shown in **FIGURE 6**.


O = C9 Red Shirt / White Short Player

□ ■ C10 One Player Stop Rod

= C4 Rod Bumper

- = C5 Rod Washer

# OVERHEAD VIEW LOOKING DOWN ONTO TABLE




#### STEP 7:


Align **C9** Red Shirt / White Short Player and **C10** One Player Stop Rod to each player hole and attach using **C6** Bolts with **C7** Lock Nut as shown in **FIGURE 7** and **DETAIL B**.

Attach **P10** Rod End Caps to the rod as shown in **FIGURE 7**.

Slide **P6** Rod Handle onto each rod end with the small hole shown in **FIGURE 7**.


**IMPORTANT NOTE:** A small amount of liquid soap applied inside each **P6** Rod Handle will allow them to slip onto rod easier.





4 pcs - **H8** Phillips Flat Head Screw 2 pcs - **P11** Scorer

STEP 8: Attach P11 Scorers using pre-drilled holes with H8 Phillips Flat Head Screws as shown in FIGURE 8. Tighten, but do not strip out H8 Screws.



Congratulations! You have now assembled your soccer table. Please note the Care and Use instructions below to insure many years of trouble free use of your soccer table.

# CARE AND USE OF YOUR SOCCER TABLE

- 1. Apply spray furniture polish to a clean cloth and wipe down the rods to make them slide easier in the rod bushings.
- 2. Use spray furniture polish to clean all exterior surfaces of your soccer table.
- 3. This product is intended for **INDOOR** use only.
- 4. **DO NOT** sit, climb or lean on the table.
- 5. **DO NOT** drag the table when moving it. This will damage the legs.
- 6. **DO NOT** set drinks on the table.

### PRODUCT PARTS LIST FOR MODEL # FT200

Key #	Part #	Description	Qty.
P1	RPFT20-P1	Side Apron	2
P2	RPFT20-P2	End Apron	2
P3	RPFT20-P3	Playfield	1
P4A	RPFT20-P4A	Left Leg	2
P4B	RPFT20-P4B	Right Leg	2 2
P5	RPFT20-P5	Leg Cross Tube	2
P6	RPFT20-P6	Rod Handle	8
P7	RPFT20-P7	Playfield Support Brace	3
P9	RPFT20-P9	Wooden Ball Catcher	2
P10	RPFT20-P10	Rod End Cap	8
P11	RPFT20-P11	Scorer (Set)	2 2
C1	RPFT20-C1	5 Player Rod	2
C2	RPFT20-C2	3 Player Rod	4
C3	RPFT20-C3	2 Player Rod	2
C4	RPFT20-C4	Rod Bumper	16
C5	RPFT20-C5	Rod Washer	32
C6	RPFT20-C6	4mm x 25mm Phillips Round Head Bolt	26
C7	RPFT20-C7	4mm Nut	26
C8	RPFT20-C8	Blue Shirt / White Short Player	11
C9	RPFT20-C9	Red Shirt / White Short Player	11
C10	RPFT20-C10	One Player Rod Stoper	4
H1	RPFT20-H1	3.5mm x 25mm Phillips Round Head Screw	8
H3	RPFT20-H3	Playfield Support Rod	3
H4	RPFT20-H4	Allen Head Nut for Playfield Support Rod	6
H5	RPFT20-H5	3.5mm x 25mm Phillips Round Head Screw	8
H6	RPFT20-H6	7.5mm x 50mm Allen Head Bolt	24
H7	RPFT20-H7	8.5mm x 19mm Flat Washer	24
H8	RPFT20-H8	3.5mm x 32mm Phillips Flat Head Screw	4
A1	RPFT20-A1	Soccer Ball	2
A2	RPFT20-A2	6mm Allen Wrench	2
A3	RPFT20-A3	4mm Allen Wrench	1

## 90 DAY LIMITED WARRANTY

This consumer warranty extends to the original consumer purchase of any ESCALADESPORTS Product (hereinafter referred as the "Product").

**WARRANTY DURATION:** This Product is warranted to the original consumer purchase of a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

**WARRANTY PERFORMANCE:** During the above 90 day warranty period, ESCALADESPORTS shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Dept.

1-888-996-2729 / Warranty Dept.
Or Write us at:
Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706
Attn: Warranty Dept.
Or E-mail us at:
gameroom@escaladesports.com

Other than shipping requirements no charge will be made for such repair or replacement of inwarranty Products. ESCALADE SPORTS strongly recommends that the Product is insured for value prior to mailing.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

**LEGAL REMEDIES:** This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.