Round Dining Table

IMPORTANT NOTE

This product is made of sturdy, high quality aluminum and will provide years of enjoyment. Do not use power tools to assemble and only tighten bolts until they are snug. Over tightening can cause damage to the aluminum.

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occuring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly

Key Wrench 1 pc.

4 pcs.(+1 extra)

Bolt




Cover

1 pc.

Nut Cap 12 pcs.(+1 extra)

12 pcs.(+1 extra)



Spring Washer 12 pcs.(+1 extra)

Flat Washer

12 pcs.(+1 extra)

Assembly Instructions

IMPORTANT

- * Do not use power tools to assemble and do not overtighten the bolts.
- * Do not tighten up all the bolts until each part is properly assembled.
- * You should keep Key Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.

* After assembly, item must be level to work properly. Use the included adjustable levelers to level. Nut Cap Nut Spring Washer STEP 1 Flat Washer Assemble Legs (B) and Side Frames (C) with Flat Washers, Spring Washers, Nuts and Nut Caps. (See Figure 1 and Figure 2) Figure 1 Figure 2 Figure 3 STEP 2 Insert Bolts into the pre-drilled holes of Top (A), using a Nut Cap Slotted Screwdriver. Spring Washer (See Figure 3) Flat Washer Attach unit to Top (A) with Flat Washers, Bolt Spring Washers, Nuts and Nut Caps. Cove STEP 3 Turn the table to its' upright position. Cover the umbrella hole with Cover. To level the table, adjust the adjustable levelers on the bottom of the legs. (See Figure 4)

Figure 4